Page 1/2

```
Nov 10, 24 13:52 goals6step8.py
```

```
"""goals6simple.py
2
     Read the camera image in preparation for some image manipulation
3
4
     and object detection.
5
    # Import OpenCV
8
9
   import cv2
10
    # Set up video capture device (camera). Note 0 is the camera number.
11
   # If things don't work, you may need to use 1 or 2?
12
   camera = cv2.VideoCapture(0, cv2.CAP_V4L2)
13
   if not camera.isOpened():
14
        raise Exception ("Could not open video device: Maybe change the cam number?")
15
    # Change the frame size and rate. Note only combinations of
17
   # widthxheight and rate are allowed. In particular, 1920x1080 only
18
   # reads at 5 FPS. To get 30FPS we downsize to 640x480.
camera.set(cv2.CAP_PROP_FRAME_WIDTH, 640)
19
20
   camera.set(cv2.CAP_PROP_FRAME_HEIGHT, 480)
21
   camera.set(cv2.CAP_PROP_FPS,
22
23
   # Change the camera settings.
24
25
   exposure = 235
   wb = 3273
26
27
   focus = 0
28
    #camera.set(cv2.CAP_PROP_AUTO_EXPOSURE, 3)
29
                                                              # Auto mode
   camera.set(cv2.CAP_PROP_AUTO_EXPOSURE, 1)
                                                              # Manual mode
30
                                                             # 3 - 2047, default 250
   camera.set(cv2.CAP_PROP_EXPOSURE, exposure)
31
32
   #camera.set(cv2.CAP_PROP_AUTO_WB, 1.0)
camera.set(cv2.CAP_PROP_AUTO_WB, 0.0)
camera.set(cv2.CAP_PROP_WB_TEMPERATURE, wb)
                                                              # Enable auto white balance
                                                              # Disable auto white balance
34
                                                              # 2000 - 6500, default 4000
35
    #camera.set(cv2.CAP_PROP_AUTOFOCUS, 1)
37
                                                               # Enable autofocus
   camera.set(cv2.CAP_PROP_AUTOFOCUS, 0)
                                                              # Disable autofocus
38
   camera.set(cv2.CAP_PROP_FOCUS, focus)
                                                              # 0 - 250, step 5, default 0
39
40
   camera.set(cv2.CAP_PROP_BRIGHTNESS, 154)
                                                              \# 0 - 255, default 128
41
                                                             # 0 - 255, default 128
# 0 - 255, default 128
   camera.set(cv2.CAP_PROP_CONTRAST, 128)
camera.set(cv2.CAP_PROP_SATURATION, 210)
42
43
44
45
    # Keep scanning, until 'q' hit IN IMAGE WINDOW.
46
   count = 0
47
   while True:
48
49
        # Grab an image from the camera. Often called a frame (part of sequence).
50
        ret, frame = camera.read()
        count += 1
51
52
        # Grab and report the image shape.
53
        (H, W, D) = frame.shape
54
        #print(f"Frame #{count:3} is {W}x{H} pixels x{D} color channels.")
55
57
        # Convert the BGR image to RGB or HSV.
        hsv = cv2.cvtColor(frame, cv2.COLOR_BGR2HSV)
                                                                     # For other objects
58
        # hsv = cv2.cvtColor(frame, cv2.COLOR_RGB2HSV)
                                                                      # For red objects
59
60
        # Print color of center pixel
61
        print ('BGR at center pixel:', frame [W//2, H//2])
print ('HSV at center pixel:', hsv[W//2, H//2])
62
63
64
65
        # Cross hair on center pixel
66
         (xA1, yA1) = (W // 2, 0)
67
         (xA2, yA2) = (W // 2, H - 1)

(xB1, yB1) = (0, H // 2)
68
69
        (xB2, yB2) = (W - 1, H // 2)
70
        cv2.line(frame, (xA1, yA1), (xA2, yA2), (0,0,255), 1) cv2.line(frame, (xB1, yB1), (xB2, yB2), (0,0,255), 1)
71
72
73
74
        binary = cv2.inRange(hsv, (75, 115, 50), (115, 230, 190))
75
        binary = cv2.erode(binary, None, iterations=3)
77
        binary = cv2.dilate(binary, None, iterations=1)
78
         # Add contours
79
         (contours, hierarchy) = cv2.findContours(binary, cv2.RETR_LIST, cv2.CHAIN_APPROX_SIMPLE)
```

Nov 10, 24 13:52

## goals6step8.py

Page 2/2

```
contours = sorted(contours, key=cv2.contourArea, reverse=True)
       # cv2.drawContours(frame, contours, -1, (0,0,255), 2)
82
83
        CUTOFF = 1000
84
85
86
        for contour in contours:
            if cv2.contourArea(contour) > CUTOFF:
87
                 cv2.drawContours(frame, [contour], 0, (0,255,0), 2)
88
89
                 # single contour centroid method
90
                 # M = cv2.moments(contour)
91
                 # area = M['m00']
92
                 \# x_c = int(M['m10'] / M['m00'])
93
                 \# y_c = int(M['m01'] / M['m00'])
94
95
                 # fit an ellipse to a single contour
97
                 # ellipse = cv2.fitEllipse(contour)
                 # ((xe, ye), (w, h), angle) = cv2.fitEllipse(contour)
98
                 # cv2.ellipse(frame, ellipse, (0,255,255), 2)
99
                 \# x_c = xe + w/2
100
                 # y_c = ye + h/2
# print(f'({xe}, {ye})')
101
102
103
                 # cv2.circle(frame, (int(xe), int(ye)), 4, (0, 255, 255), -1)
            else:
104
105
                 cv2.drawContours(frame, [contour], 0, (0,0,255), 2)
106
        # Show the processed image with the given title. Note this won't
107
        # actually appear (draw on screen) until the waitKey(1) below.
cv2.imshow('Processed Image', frame)
108
109
        cv2.imshow('Binary Image', binary)
110
111
        # Check for a key press IN THE IMAGE WINDOW: waitKey(0) blocks
112
        # indefinitely, waitkey(1) blocks for at most 1ms. If 'q' break.
113
        # This also flushes the windows and causes it to actually appear.
114
        if (cv2.waitKey(1) \& 0xFF) == ord('q'):
115
116
            break
117
   # Close everything up.
118
119 camera.release()
   cv2.destroyAllWindows()
```